

CREATE  
your STYLE™  
with CRYSTALLIZED™ – Swarovski Elements

# ON THE RUN BRACELET



# ON THE RUN BRACELET



## CRYSTALLIZED™ – Swarovski Elements

| Article  | Product Group | Article No. | Amount | Size | Color         | Color Code | Supplies   |
|--|---------------|-------------|--------|------|---------------|------------|--|
|  | Beads         | 5000        | 5      | 3 mm | Jet           | 280        | Nylon thread, 5 mm, black<br>Elastic thread, 1 mm, black<br>Hypo-cement jewelry glue |
|  | Beads         | 5000        | 5      | 6 mm | Jet           | 280        |  |
|  | Beads         | 5000        | 5      | 4 mm | Jet Hematite  | 280 HEM    |  |
|  | Beads         | 5000        | 5      | 6 mm | Jet Hematite  | 280 HEM    |  |
|  | Beads         | 5000        | 5      | 8 mm | Jet Hematite  | 280 HEM    |  |
|  | Beads         | 5000        | 5      | 6 mm | Black Diamond | 215        |  |
|  | Beads         | 5000        | 5      | 8 mm | Black Diamond | 215        |  |
|  | Beads         | 5301        | 5      | 4 mm | Black Diamond | 215        | <b>Tools:</b><br>Scissors<br>Butane Lighter<br>Fine-tipped tweezers                  |
|  | Beads         | 5301        | 5      | 6 mm | Black Diamond | 215        |  |
|  | Beads         | 5301        | 5      | 4 mm | Jet           | 280        |  |

Prepare the bracelet foundation:

### STEP 1

- Cut a length of elastic thread to 10" (25cm).
- Create a circle with the ends and tie a square knot.
- Tie overhand knots to each tail placing them near the square knot.

### STEP 2

- Dot knots with glue. Set aside to dry.
- Trim ends to 3/8" (10cm).

Embellish with crystal components:

### STEP 3

- Cut a length of nylon thread to 2" (5cm).
- Tie the length around the elastic foundation, leaving equal length tails.

### STEP 4

Alternate adding the top half (in random order) of each of three sets of crystal components outlined in Step 7.

- Add the top components of (Start with Set A) to one tail thread.
- Push the crystals flush to the knot and trim the end to .25" (7mm).

### STEP 5

- Hold the crystals taut against the tail of the knot with a tweezers with one hand. Hold the flame of a butane lighter next to the tail and carefully burn a ball up to the crystal, creating a knot that will secure them. (Note: Working with flame and the melted nylon ball is extremely hot. Keep fingers away).

### STEP 6


- Add the bottom components (match Set A bottom to Set A top, etc.) to the remaining tail end.
- Repeat Step 5 to secure the crystals in place.
- Repeat Steps 4 and 5 around the bracelet with crystal sets A, B, and C until bracelet reaches desired fullness. (Note: Recommended fullness uses every crystal listed in the material section.)

### STEP 7


Finished Set combinations:

- SET A: Top – 8 mm Art. 5000 Jet Hematite, then 4 mm Art. 5301 Black Diamond.
- SET B: Top – 6 mm Art. 5000 Jet, then 4 mm Art. 5000 Jet Hematite; Bottom – 6 mm Art. 5000 Black Diamond, then 4 mm Art. 5301 Jet.
- SET C: Top – 6 mm Art. 5301 Black Diamond, then 4 mm Art. 5301 Jet. Bottom – 6 mm Art. 5000 Jet Hematite, then 3 mm Art. 5000 Jet.


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



Repeat Step 4+5



STEP 7



Repeat Step 3-6

